

FIG.1




FIG. 2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7




FIG.8




FIG.9

10/10

RECORDING DIRECTION
→

"15"

CHANNEL BIT TRAIN

"27"

"28"

"29"

FIG.10